

PM-112 SILNET CLEAN

FILTER DESCALER CLEANER

PM-122 SILNET CLEAN: Special descaling and degreasing product for regenerating silex or filter glass. Removes lime scale and degreases the filter bed, dissolves grease and dirt, optimising filter performance. Also suitable for cleaning diatom earth filters.



METHOD OF USE AND DOSAGE

Sand or glass filters:

- Use the attached table to calculate the dosage according to the filter diameter.

ø (mm)	Kg PM-122
400 - 600	1.2
600 - 800	2.4
800 - 1000	6
1000 - 1200	12
1200 - 1400	18
1400 - 1600	24

- Introduce the product directly onto the filter bed, or through the pump pre-filter, running the pump for a few seconds to get the product into the filter.
- If placed directly on the filter, it is recommended to shake the bed with a stick or similar to promote the introduction of the product into the bed.
- Leave to work for 8 to 12 hours.
- Carry out a filter wash to remove dirt and product residues.

Diatom earth filters:

- Dissolve 1.2 kg of product in 10 L of water.
- Immerse the diatom earth filter plates in the solution and leave to work for 8 - 12 hours.

- Rinse with plenty of water to remove product residues.

PHYSICAL PROPERTIES

- Aspect: White solid
- Odour: Odourless
- pH: 1 – 2 (1% solution)

PRECAUTIONS

- Keep the area well ventilated.
- Use appropriate PPE, at least gloves and protective glasses.

PACKAGING

Packaged in 1,2 and 6 Kg.